



BLEEDING CONTROL

USE DIRECT PRESSURE OVER THE WOUND.



IF NOT CONTROLLED BY DIRECT PRESSURE, USE PRESSURE POINTS B OR C.



SQUEEZE THE ARTERY BETWEEN YOUR FINGERS AND THE UPPER ARM BONE.

FOR SERIOUS BLEEDING OF THE LEG, USE THE HEEL OF THE HAND TO SQUEEZE THE ARTERY BETWEEN THE HAND AND THE PELVIS.

USE PRESSURE POINTS ONLY LONG ENOUGH TO ALLOW BLOOD TO CLOT AND FORM AN ARTIFICIAL DAM.

